PARTS LIST

for

KitchenAid®

5 QT. STAND MIXER

PRO 500 - LIFT

MODELS:

KSM500PSWH0 (White) KSM500PSER0 (Empire Red) KSM500PSOB0 (Onyx Black) KSM500PSSM0 (Silver Metallic)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID ST, JOSEPH MICHIGAN 49085

COLOR VARIATION PARTS

FOR MODELS:KSM500PS_0



COLOR VARIATION PARTS

Illus.


Part

FOR MODELS:KSM500PS_0

No.	No.	DESCRIPTION
1		Motor Housing
1	240204 4	Motor Housing White
	240291-1	
	240291-21	Empire Red
	240291-13	Onyx Black
2	W10121193	Silver Metallic Trim Band
	W10158179	Black
3	040054 0	Lower Gearcase
	240354-3	White
	9704499	Empire Red
	240354-43	Onyx Black
	W10158521	Silver Metallic
4		Planetary
	240286–1	White
	240286-23	Empire Red
	240286–16	Onyx Black
_	W10121190	Silver Metallic
5		End Cover
	240253-1	White
	240253–22	Empire Red
	240253–14	Onyx Black
_	W10121188	Silver Metallic
6		Bowl Support
		And Pins
	3179300	White
	3179318	Empire Red
	3179311	Onyx Black
	W10158518	Silver Metallic
7		Column
	240148–4	White
	9702393	Empire Red
	240148–15	Onyx Black
	W10158516	Silver Metallic
8		Base & Foot
		Assembly
	3179280	White
	3179299	Empire Red
	3179292	Onyx Black
	W10158515	Silver Metallic

Colors Subject To Change. Any Color Not Listed is No Longer Available. If Additional Colors Are Added, This Page Will Be Updated.

CASE, GEARING AND PLANETARY UNIT FOR MODELS: KSM500PS_0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT FOR MODELS:KSM500PS_0

Illus No		DESCRIPTION
1	*ok	Motor Housing
2	242765–2	Motor Housing Cap, Attachment
_		Hub
3	9709194	Thumb Screw
4		Band, Trim
5 6	3180161 W10112253	Washer, Fiber Gear, Worm
7	240308	Worm Gear Bracket
•		and Bearing
8	9705444	Pin
9	240210-2	Shaft & Pinion
10	9705130	Gear, Attachment Hub Bevel
11	9709627	Bevel Pinion
• • •	3703027	and Center Gear
12	240026	Shaft, Vertical
		Center
13	240018–1	Pin (Vertical
14	9705443	Center Shaft) Pin, Groove
15	4162324	Gasket, Transmssn
16	67500-55	"O" Ring
17	3180163	Washer
18		Lower Gearcase
19 20	103994 4176067	Screw Shaft, Agitator
21	9703438	Ring, Retaining
22	9704677	Pin, Groove
23	4162914	Screw
24	**	Cover, End
25 26	311932 3400022	Screw Screw
27	240309-2	Worm Gear Bracket
	210000 2	and Gear
28	4160474	Center Shaft and
00	0.400005	"O" Ring
30 31	3400025 3400026	Screw Screw
32	9703903	Pinion, Gear
52	3703303	(Agitator Shaft)
33	9706090	Washer, Shim
34	**	Planetary
35	240285	Ring, Planetary
36	9703904	Drip Gear, Internal
50	U, 0000 1	Cour, intornar

**Refer to Page 3
Color Variation Parts

MOTOR AND CONTROL PARTS FOR MODELS: KSM500PS_0




MOTOR AND CONTROL PARTS

FOR MODELS:KSM500PS_0

Illus No.	. Part No.	DESCRIPTION
4	440670	Corour Divot
1	110679 116241	Screw, Pivot
2	110241	Washer, Spring Lever, Speed
3		Control Assembly
	9709276	Black
4	3183680	Spring, Control
4	3103000	Plate
5	9704324	Washer, Ball
3	3704324	Bearing (Front)
6	9708315	Armature & Bearing
O	3700010	Assembly
7	3180162	Washer
8	16998	Stud, Governor Drv
9	3180526	Bracket, Bearing
		Assembly
10	240775-1	Seal, End
11	W10131078	Nut
12	3180238	Washer
13	240769	Screw, Stator
14	W10068270	Washer, Lock
15	3184176	Speed Link & Cam
16	240205	Spring, Flat
17	9702695	Field Assembly
18	4162634	Sleeve, Motor Stud
19	9706416	Brush & Spring
00	0707000	Assembly
20	9707926	Screw, Set
21 22	4162546 3179908	Brush Holder Assy
22	3179908	Housing, Brush Holder
23	240680	
23	240000	Insert, Brush Holder
24	116286	Cap, Spring
- '	110200	Seat
25	116287	Spring, Cap
26	3184212	Cap, Brush Holder
27	W10068260	Screw
28	W10119326	Control Plate
		Assembly
29	17830	Governor Assembly
30	9706595	Phase Control
		Board
31		Cord, Power
	W10164883	Black
_	W10164882	White
32	3184609	Screw, Self Tap

BASE AND PEDESTAL UNIT

FOR MODELS:KSM500PS_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

FOR MODELS:KSM500PS_0

Illus No.		DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26	9706634 W10184246 9709923 4162161 240185 3182857 3400024 *** 9708649 9704608 9085 240169 WS00323 9237 8533907 3182904 3180500 240235–4 3183233 9704309 241764 240912 9703442 9079	Literature Parts Use & Care Guide Repair Parts List Shield, Pouring Bowl, 5 Qt. Pin, Bowl Locating Latch, Bowl Spring Screw Bowl Support & Pns Base & Foot Assy Foot Pin, Cotter Rod, Bowl Lift Bracket, Bowl Lift Washer Spring Nut Screw Pin, Dowel Beater, Flat Hook, Dough Whip, Wire Arm, Bowl Lift Screw Pin, Roll Handle, Bowl Lift Column Assembly
-		

**Refer to Page 3 Color Variation Parts

ACCESSORY PARTS

FOR MODELS: KSM500PS 0

Illus. Part

No. No. DESCRIPTION

FOLLOWING PARTS NOT ILLUSTRATED

4164778 Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A) 4164749 Food Grinder (FGA) 8211924 Grain Mill (KGMA) 4164768 Pasta Maker And Food Grinder (Includes SNP **Pasta Maker** Plates) (SN/FG-A) 4164775 Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP) 4164750 Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A) 3177975 Pouring Shield (KPS2ČL) 4164824 Pasta Maker Plates (SNP-A) 4164774 Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A) 3180616 Cover, Decorative (Cotton Polyester) 4162838 Food Tray (FT) 4164748 Juicer (JÉ) 4164747 Can Opener (CO) 4164803 Sausage Stuffer Kit (SSA) 4162154 Water Jacket (K5AWJ) 3177925 Bowl Cover, Plastic Non-Sealing 4176100 5 Qt. Bowl. Polished Stainless Steel 4164839 Speed Disc (Service Tool) 4160588 Grease, Planetary 8212519 Ice Cream Maker (KICA0WH0)

10